

Any Bus

Garanti: 12 ay
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin **info@yursat.com.tr** e-posta adresine bařvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulařabilirsiniz.
Any Bus Markası, tedarik sresi iin ltfen bizimle iletiřime geiniz.

Firmamız Any Bus Trkiye Distribtr veya temsilcisi deēildir. Firmamız sipariř durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.



rn	Aıklama
Ab7607	DEVICENET SCANNER/MASTER TO ETHERNET/IP ADAPTER/SLAVE
Ab7886	INTERBUS SLAVE TO CC-LINK SLAVE
Ab7834	ETHERNET/IP ADAPTER/SLAVE TO CONTROLNET ADAPTER/SLAVE
Ab7693	ETHERCAT SLAVE TO MODBUS PLUS SLAVE
Ab7628	LONWORKS TO LONWORKS
Ab7892	INTERBUS FIBER OPTIC SLAVE TO CC-LINK SLAVE
Ab7876	FIP IO SLAVE TO CANOPEN SLAVE
Ab7853	PROFIBUS SLAVE TO LONWORKS
Ab7869	CONTROLNET ADAPTER/SLAVE TO MODBUS RTU SLAVE
Ab7913	PROFINET IRT SLAVE TO PROFIBUS SLAVE
Ab7871	CONTROLNET ADAPTER/SLAVE TO CC-LINK SLAVE

Ab7898	CANOPEN SLAVE TO LONWORKS
Ab7873	FIP IO SLAVE TO FIP IO SLAVE
Ab7868	CONTROLNET ADAPTER/SLAVE TO CANOPEN SLAVE
Ab7662	PROFINET I/O SLAVE TO LONWORKS
Ab7808-F	RTU SLAVE 24VDC
Ab7309	CANOPEN MASTER TO PROFINET IRT SLAVE
Ab7881	INTERBUS SLAVE TO INTERBUS SLAVE
Ab7655	PROFINET I/O SLAVE TO FIP IO SLAVE
Ab7623	MODBUS PLUS SLAVE TO MODBUS PLUS SLAVE
Ab7813	DEVICENET SCANNER/MASTER TO FIP IO SLAVE
Ab7803	PROFIBUS MASTER TO CONTROLNET ADAPTER/SLAVE
Ab7877	FIP IO SLAVE TO MODBUS RTU SLAVE
Ab7814	DEVICENET SCANNER/MASTER TO INTERBUS SLAVE
Ab7885	INTERBUS SLAVE TO MODBUS PLUS SLAVE
Ab7887	INTERBUS SLAVE TO LONWORKS
Ab7679	ETHERNET/IP SCANNER/MASTER TO MODBUS PLUS SLAVE
Ab7676	ETHERNET/IP SCANNER/MASTER TO INTERBUS FIBER OPTIC SLAVE
Ab7687	ETHERCAT SLAVE TO CONTROLNET ADAPTER/SLAVE
Ab7914	PROFINET IRT SLAVE TO INTERBUS SLAVE
Ab7625	MODBUS PLUS SLAVE TO LONWORKS
Ab7944	PROFINET IRT SLAVE FO TO PROFIBUS SLAVE
Ab7673	ETHERNET/IP SCANNER/MASTER TO CONTROLNET ADAPTER/SLAVE
Ab7638	MODBUS/TCP SLAVE TO INTERBUS SLAVE
Ab7656	PROFINET I/O SLAVE TO INTERBUS SLAVE
Ab7848	PROFIBUS SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab7863	DEVICENET ADAPTER/SLAVE TO LONWORKS
Ab7689	ETHERCAT SLAVE TO INTERBUS SLAVE
Ab7883	INTERBUS SLAVE TO CANOPEN SLAVE
Ab7660	PROFINET I/O SLAVE TO MODBUS PLUS SLAVE

Ab7809	PROFIBUS MASTER TO MODBUS PLUS SLAVE
Ab7884	INTERBUS SLAVE TO MODBUS RTU SLAVE
Ab7829	AS-INTERFACE MASTER TO MODBUS PLUS SLAVE
Ab7845	PROFIBUS SLAVE TO CONTROLNET ADAPTER/SLAVE
Ab7874	FIP IO SLAVE TO INTERBUS SLAVE
Ab7893	INTERBUS FIBER OPTIC SLAVE TO LONWORKS
Ab7639	MODBUS/TCP SLAVE TO INTERBUS FIBER OPTIC SLAVE
017505	ANYBUS COMMUNICATOR CAN GATEWAY PROFIBUS-DPV1 MASTER SIMULATOR (COM PORT)
Ab7940	PROFINET IRT SLAVE TO DEVIENET SLAVE
Ab7856	DEVICENET ADAPTER/SLAVE TO FIP IO SLAVE
Ab7855	DEVICENET ADAPTER/SLAVE TO CONTROLNET ADAPTER/SLAVE
Ab7303	CANOPEN MASTER TO CONTROLNET ADAPTER/SLAVE
Ab7835	ETHERNET/IP ADAPTER/SLAVE TO FIP IO SLAVE
Ab7840	ETHERNET/IP ADAPTER/SLAVE TO MODBUS PLUS SLAVE
018410	ANYBUS COMMUNICATOR CAN GATEWAY DEVICENET MASTER SIMULATOR (USB PORT)
Ab7851	PROFIBUS SLAVE TO MODBUS PLUS SLAVE
Ab7688	ETHERCAT SLAVE TO FIP IO SLAVE
Ab7888	INTERBUS FIBER OPTIC SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab7878	FIP IO SLAVE TO MODBUS PLUS SLAVE
Ab7842	ETHERNET/IP ADAPTER/SLAVE TO LONWORKS
Ab7804	PROFIBUS MASTER TO FIP IO SLAVE
Ab7624	MODBUS PLUS SLAVE TO CC-LINK SLAVE
Ab7637	MODBUS/TCP SLAVE TO FIP IO SLAVE
Ab7870	CONTROLNET ADAPTER/SLAVE TO MODBUS PLUS SLAVE
Ab7889	INTERBUS FIBER OPTIC SLAVE TO CANOPEN SLAVE
Ab7882	INTERBUS SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab7806	PROFIBUS MASTER TO INTERBUS FIBER OPTIC SLAVE
Ab7943	PROFINET IRT SLAVE FO TO CANOPEN SLAVE

Ab7858	DEVICENET ADAPTER/SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab7636	MODBUS/TCP SLAVE TO CONTORLNET ADAPTER/SLAVE
Ab7818	DEVICENET SCANNER/MASTER TO MODBUS PLUS SLAVE
Ab7627	CC-LINK SLAVE TO LONWORKS
Ab7837	ETHERNET/IP ADAPTER/SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab9003	MODBUS TCP CLIENT TO CONTROLNET ADAPTER/SLAVE
Ab7674	ETHERNET/IP SCANNER/MASTER TO FIP IO SLAVE
Ab7867	CONTROLNET ADAPTER/SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab7941	PROFINET IRT SLAVE TO CONTRONET SLAVE
Ab7695	ETHERCAT SLAVE TO LONWORKS
Ab7675	ETHERNET/IP SCANNER/MASTER TO INTERBUS SLAVE
Ab7812	DEVICENET SCANNER/MASTER TO CONTROLNET ADAPTER/SLAVE
Ab7642	MODBUS/TCP SLAVE TO MODBUS PLUS SLAVE
Ab7879	FIP IO SLAVE TO CC-LINK SLAVE
Ab7891	INTERBUS FIBER OPTIC SLAVE TO MODBUS PLUS SLAVE
Ab7805	PROFIBUS MASTER TO INTERBUS SLAVE
Ab7861	DEVICENET ADAPTER/SLAVE TO MODBUS PLUS SLAVE
Ab7915	PROFINET IRT SLAVE TO CANOPEN SLAVE
Ab7865	CONTROLNET ADAPTER/SLAVE TO FIP IO SLAVE
Ab7824	AS-INTERFACE MASTER TO FIP IO SLAVE
Ab7846	PROFIBUS SLAVE TO FIP IO SLAVE
Ab7826	AS-INTERFACE MASTER TO INTERBUS FIBER OPTIC SLAVE
Ab7875	FIP IO SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab7644	MODBUS/TCP SLAVE TO LONWORKS
Ab7815	DEVICENET SCANNER/MASTER TO INTERBUS FIBER OPTIC SLAVE
Ab7654	PROFINET I/O SLAVE TO CONTROLNET ADAPTER/SLAVE
Ab7620	MODBUS RTU SLAVE TO MODBUS PLUS SLAVE
Ab7847	PROFIBUS SLAVE TO INTERBUS SLAVE

Ab7690	ETHERCAT SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab7657	PROFINET I/O SLAVE TO INTERBUS FIBER OPTIC SLAVE
Ab7866	CONTROLNET ADAPTER/SLAVE TO INTERBUS SLAVE
Ab7864	CONTROLNET ADAPTER/SLAVE TO CONTROLNET ADAPTER/SLAVE
Ab7896	CANOPEN SLAVE TO MODBUS PLUS SLAVE
Ab7880	FIP IO SLAVE TO LONWORKS
Ab7890	INTERBUS FIBER OPTIC SLAVE TO MODBUS RTU SLAVE
Ab7836	ETHERNET/IP ADAPTER/SLAVE TO INTERBUS SLAVE
Ab7823	AS-INTERFACE MASTER TO CONTROLNET ADAPTER/SLAVE
Ab7825	AS-INTERFACE MASTER TO INTERBUS SLAVE
Ab7872	CONTROLNET ADAPTER/SLAVE TO LONWORKS
Ab7942	PROFINET IRT SLAVE TO ETHERNET/IP SLAVE
Ab7857	DEVICENET ADAPTER/SLAVE TO INTERBUS SLAVE