

DD

Garanti: 12 ay
Bu ürüne ait Türkiye içi kapı teslim fiyat ve teslim süresi içeren teklifimizi almak için **info@yursat.com.tr** e-posta adresine başvuru yapabilir ya da ayrıntılı bilgi için +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaşabilirsiniz.
DD Markası, tedarik süresi için lütfen bizimle iletişime geçiniz.

Firmamız DD Türkiye Distribütörü veya temsilcisi değildir. Firmamız sipariş durumunda, belirtilen ürünlerde sadece Orjinal ve yeni ürün teklifi sunmaktadır. Bu sitede gösterilen Özel marka adları ve ticari markalar ilgili sahiplerinin mülkiyetindedir, talep durumunda kaldırılmaktadır.



Ürün	Açıklama
DD700.002.000	DD700-IC ANALOG (stainless steel with plug, only front side IP65) 5V load cell supply with table base (max. 4 load cells) basic device with table base Weighing terminal DD700-IC ANALOG for connection to a scale. up to max. 4 load cells with 2-range scales up to max. 8 load cells with 1-range scales ! Check proof of compatibility!
DD700.001.000	DD700-I ANALOG 5V load cell supply (stainless steel, IP68 / 69K) including wall bracket (max. 4 load cells) basic device with screwed cable gland including wall bracket Weighing terminal DD700-I ANALOG for connection to a scale. up to max. 4 load cells with 2-range scales up to max. 8 load cells with 1-range scales ! Check proof of compatibility! Basic device without wall or table bracket (must be ordered separately): - Optionally, a 2nd scale can be connected (counting scale function) - stainless steel case - Protection class IP 68 / IP 69K - Load cell supply voltage: 5V - Load cell impedance per scale: 29 to 1100 ohms - 1 RS 232 - 1 RS 232/422/485 - 1 USB port (host) - 1 USB port (client) - 2 free slots for expansions - 2 outputs 24V AC / DC 190mA - 2 inputs 5VDC (via pot-free contact)

[DD700.000.000](#)

DD700 ANALOG 5V load cell supply (ABS) (max. 4 load cells with 2-range) basic device, table version Weighing terminal DD700 ANALOG for connection to a scale. up to max. 4 load cells with 2-range scales up to max. 8 load cells with 1-range scales ! Check proof of compatibility! Basic device for table installation - Optionally, a 2nd scale can be connected (counting scale function) - ABS plastic case - Load cell supply voltage: 5V - Load cell impedance per scale: 29 to 1100 ohms - 1 RS 232 - 1 RS 232/422/485 - 1 USB port (host) - 1 USB port (client) - 2 free slots for expansions - 2 outputs 24V AC / DC 190mA - 2 inputs 5VDC (via pot-free contact)