

## Kearney & Trecker

Garanti: 12 ay  
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin **info@yursat.com.tr** e-posta adresine bařvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulařabilirsiniz.  
**Kearney & Trecker** Markası, tedarik sresi iin ltfen bizimle iletiřime geiniz.

*Firmamız Kearney & Trecker Trkiye Distribtr veya temsilcisi deęildir. Firmamız sipariř durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.*



| rn                          | Aıklama              |
|-------------------------------|-----------------------|
| <a href="#">1-21241</a>       | ASSEMBLY              |
| <a href="#">81-1020604-00</a> | CPU CONTROL ASSEMBLY  |
| <a href="#">1-21296</a>       | PC BOARD ADD ON       |
| <a href="#">871-20640-00</a>  | PC BOARD COMPUTER     |
| <a href="#">1-21234-06</a>    | ANALOG INTF BD        |
| <a href="#">1-20667-01</a>    | CRT CTRL BOARD        |
| <a href="#">1-21234-05</a>    | ANALOG INTF BD        |
| <a href="#">1-20615</a>       | PC BOARD PIC ASSEMBLY |
| <a href="#">1-21295-01</a>    | CONTROL MOTHERBOARD   |
| <a href="#">1-21271-03</a>    | MEMORY BOARD          |
| <a href="#">1-21744-02</a>    | I/O CONTROL BD        |
| <a href="#">871-20601-01</a>  | CMUX BOARD            |

|                                      |                                  |
|--------------------------------------|----------------------------------|
| <a href="#">810-21276-03</a>         | PC COMPUTER BOARD                |
| <a href="#">1-20601</a>              | CMUX BOARD                       |
| <a href="#">1-21292</a>              | POWER MODULE 50/60HZ             |
| <a href="#">Ttr-2953-4201-3-47-L</a> | MOTOR                            |
| <a href="#">810-21762-01</a>         | MCP ASSEMBLY                     |
| <a href="#">1-21205-04</a>           | PICII BOARD                      |
| <a href="#">1-20640</a>              | I/O BOARD                        |
| <a href="#">810-21234-05</a>         | A/D CONVERTOR INTERFACE SLOT6    |
| <a href="#">1-21976-00</a>           | CONTROL DISK MODULE              |
| <a href="#">810-21282-00</a>         | AC OUTPUT DRIVER BOARD           |
| <a href="#">1-20661-01</a>           | FDBK SUBSYSTEM                   |
| <a href="#">1-20613</a>              | PC BOARD POWER SUPPLY INTERLOCK  |
| <a href="#">1-20696-06/1-21273</a>   | PC BOARD ICRTC EXTENSION         |
| <a href="#">1-20652</a>              | DRIVER BOARD                     |
| <a href="#">871-21205-08</a>         | PC BOARD COMPUTER                |
| <a href="#">1-20697-02</a>           | INTERFACE BOARD                  |
| <a href="#">1-2197701</a>            | CONTROL MODULE POWER SUPPLY 60HZ |
| <a href="#">1-20604</a>              | CPU BOARD                        |
| <a href="#">810-21712-02</a>         | PC BOARD 24V OUTPUT              |
| <a href="#">1-2142000</a>            | POWER SUPPLY MODULE              |
| <a href="#">1-21711</a>              | PC BOARD                         |
| <a href="#">120661</a>               | PC BOARD                         |
| <a href="#">1-21221-02</a>           | 96K MEMORY BD                    |
| <a href="#">871-21781-02</a>         | CPU BOARD                        |
| <a href="#">19-81-20604</a>          | CPU CONTROL ASSEMBLY             |
| <a href="#">1-2069700</a>            | CRT/FRONT PANEL INTERFACE BOARD  |
| <a href="#">Ttr-2953-4201-B-47-L</a> | SERVO MOTOR                      |
| <a href="#">1-21234</a>              | ANALOG INTERFACE ASSEMBLY        |