



Lovato

Garanti: 12 ay

Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in

info@yursat.com.tr e-posta adresine başvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.

Lovato Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

Firmamız Lovato T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.

¼r¼n	A¼ıklama
Hr101ce024 (Vpe = 20 St¼ck)	
Hr302cd024 (Vpe = 8 St¼ck)	
Hr5xs21s (Vpe = 10 St¼ck)	
Hr5xs21 (Vpe = 10 St¼ck)	
Hr6x78024 (Vpe = 10 St¼ck)	
11B6301000xxxxx	Contactor - Lovato code 11B6301000xxxxx Weight 26.00kg / pc. Please select version: - 3 or 4 poles - Voltage 48V / 60V / 110V / 220V / 380V / 440V
(000735) 11G48102	
(001735) BFX1020	
000129	
000274	
000929	
001344	
001734	
002046	

[002133](#)

[002326](#)

[004006](#)

[004067](#)

[004100](#)

[004104](#)

[005238](#)

[005239](#)

[005514](#)

[006530](#)

[008907](#)

[009078](#)

[009213](#)

[009215](#)

[009216](#)

[009262](#)

[009272](#)

[009673](#)

[009678](#)

[009683](#)

[1001974548](#)

[11 B 180 40 220](#)

[11 BA 1700 1](#)

[11 BF Ê 26 00 A230 WITH CIOL 110V](#)

[11 SN1](#)

[11ÀÀ1671110](#)

[11B14500220](#)

[11BA1157424](#)

[11BF500012060](#)

[11BF5040230](#)

11BF80C00220	
11BG0022D220/003273	
11BG0910A22060	
11BG09T2A048	
11BG09T2A230	
11BG09T2D024	
11BG1201D024	
11BG1210A012	
11BGX1011 1NO1NC	
11BGX1022/003464	
11G218	
11G270	
11G272C24	
11G350	
11G383	
11SM2A68	
11SM3A84	
11SMX2211	
12V DC 31RGAM 12	
1NCP	
31 AFS 380	
31 BCE 0524	
31DRV3400	
7GN2013U51	
8 LM2T B6344	
8 LM2T C01	
8 LM2T C10	KONTAK BLOĐU
8 LM2T S120	
8 LT7 ALL M8	
8LM2TB104	
8LM2TIL103	

8LM2TIL104
8LM2TIL105
8LM2TP110
8LM2TS130
8LM2TS131
8LM2TS133
8LM2TS231
8LT7S1B
B 250 00 24 (24 V)
BA152305
BCF 0250 24
BF1210A230
BF50
BFK0910A110, 004109
BFX1011 1NO1NC
BFX1011 NUMMER 001734
BFX5003
BGF09 T4 A230
BT2N30S48S
CN2020220
CN4010024
G276
G350 2NC 1NO left
GAZ016T4B
GAZ025 3P
GAZ032T4
GN208302U51 (008913)
GV 1211 U
GX16H07U
JDY 50/P3

KBA1L12	
KBB1L03P	
KBF1-S11-EN-1088	
KPB6S11	
KXBL 11	
LODCRK12	
LPCB6742	
LPCB7113	
LPCS130	
LPCS320R421E	
LPMLB3	
LPMLB4	
LPMLB5	
LPMLM5	
LPXC10	
LPXCS01	
LPXCS10	
MC9	
MUS88 220/170.15	
PLNA1HW	
PMV50A575	
RF25.10	
RGAM12	
RGK60	
RGK60 ALIM-R1 12297 /08T 006L.F F06	
TGB88 380 / 400.0550F	
VFS114007PL	
TTV020100-CO	100/100 :V3V 0,72-3 Kv
HR101CE024	komplett
HR1XS024 (optional)	Socket

HR1XS024S (optional)	Socket
LVM25240	Level switching relay, multi-voltage 24...240VAC/DC, drain and filling function, auto. provision
8LM2TYL400	
SM1R1400	SM1R1400-009233 Motor protection switch rotary handle actuation 9 - 14A (Replacement for SM1B-40)
SMX12	SM1X1211-009264 Auxiliary contact block 1NO+1NC - installation on the side (Replacement for SMX12)
SM1P1400	MOTOR PROT.CIRC.BR. SM1P 9-14A
SM1X1211	Auxiliary contact block 1NO+1NC - installation on the side (Replacement for SMX12)
BF1810A024 3P CONTACTOR 1NO 18A AC3 24/50-60	
RF382500	Motorschutzrelais 20-25A Motor Protection Relay range 20...25A
BF3200A024	3P power contactor 15kW / 32A (AC3) - Coil voltage 24VAC 50/60Hz 3P CONTACTOR 32A AC3 - 24/50-60
G218 1NO+1NC	
11B25000220	3P power contactor 265A (AC3) - Coil voltage 220...240VAC/DC
11G350	Auxiliary contact, blade terminal connection, 2NO+1NC or 1NO+2NC, reversible
KBN2L02PV181	K series position switch with key Release V181
GAX1011A	Auxiliary contact 1NC+1NO for disconnecter GA...A or GA...D
DM3T0600	Current transformer 600/5A, for cable D30mm, for rails 40x10mm. 30x20mm, 25x25mm 10VA, class 1
BF1201A12060	
BF65T4A230	4P power contactor 100A (AC1) S - 230 VAC
G217-4	
11bf65c00125	
Bq09	
11b1250424110	4P CONTACTOR 1250A AC1 110V AC COIL
Bf32 00 A	
Pmf20 A415	
7qn1269u	
11b6300060	3P CONTACTOR B630.00 60V

11smx2211 (Pack 1x2)	
Bf25c-04/220v	
Cx03	
51adx0245b	
Bce10 24v	
11b4004sl00380	4P CONTACTOR380/415V W/O LATCH
11b6304l00220c220	4P CONTACTOR 220/240V C/W LATCH 220VDC
11b400l00380380	3P CONTACTOR380/415V C/W LATCH 380VAC
Pmv40 A575	
B1600	
Bg09 T2 A Spule 48 Vac	
Dcrk5 , By Dcr15	
11b250400440	4P CONTACTOR B250.4.00 440/480
11b250l00220220	3P CONTACTOR220/240V C/W LATCH 220VAC
Bg0040a220	
11bf8000110	
Cn25 10 220 4p	
EI005	
Bgpo9t2a	
11b630400110	4P CONTACTOR 630A 110V AC/DC COIL
000470 / Pmv20a240	
007234 8lm2ta150	
Bf26 00 D	
C4,40-220-50hz	
11-B310-4-00-220	4P CONTACTOR B310.4 220/240
Bg09 10 A Spule 48 Vac	
Exm10 18	
Bf3800d	
Pmv70 A600	
8lm2ts131 Schalter Mit Einem Kurzen	

Griff3 Positionen (Ohne Befestigungselement Basis)	
Bf16.10/220v-230v50-60hz	
11 B500 00	
8 Lm2t B102	
11b250400380	4P CONTACTOR B250.4.00 380/415
Pmv70 A240	
11-B310-00-380	CONTACTOR 450AMP 1000V 3P 380-415VAC/DC COIL
Bf95 00 E	
B630	
11 B400 00	
8lm2tcf10 (Pack 1x10)	
005216 / Pmv50a240	
B1250	
001342	
11b50040095	4P CONTACTOR B500.4.00 95/125
11b500l00220220	3P CONTACTOR220/240V C/W LATCH 220VAC
8lm2tc10 No	
Art.No. 005238 Rgam20	
Pmvf_Gsm_1	
Bgx50 00 Spule 48 Vac	
Lvm25240	
Pma60 A415	
11b400sl00380	3P CONTACTOR380/415V W/O LATCH
11b630l00220110	3P CONTACTOR 220/240V C/W LATCH 110VAC
Pmv50n A240	
Ip66 Lpcs321r421e	
Bf40000110	
11b31000200	3P CONTACTOR B310.00 200V
Exp10 11	
Dmg800	Dig. Built-in multi-measuring instruments (128x80 pixels, harmonic analysis, 100 ÷ 440VAC / 110 ÷ 250VDC)

Kbb1103p Schalter	
B630 1000	
51adx0568	
11bg0910d220	
Pma50 A240	
Exm10 12	
Pma40 240	
8lm2tall0243	
11 B180 00	
11b40040048	4P CONTACTOR B400.4.00 48V
Pmv30 A240	
11b5004sI00220	4P CONTACTOR220/240V W/O LATCH
11g218 Zul. Kontakt	
Endschalter Lovato Km B2 L12	
11b400I00110110	3P CONTACTOR110/125V C/W LATCH 110VAC
8lm2ts120 Schalter Mit Einem Kurzen Griff2 Positionen (Ohne Befestigungselement Basis)	
Pmv40 A240	
11b500400110	4P CONTACTOR 520A 110V AC/DC COIL
11b63040048	4P CONTACTOR B630.4.00 48V
002411 / Pmv55a240	
Pmv40 A600	
11b4000024	3P CONTACTOR B400.00 24V
8lm2tall0244	
8lm2tau120 Haltevorrichtung Basis	
8lm2tc01 Kontaktelement	
Kxbl 11 Contacts 1no+1nc Slow Break, Make Before Break	
11g218 Nummer 000188	
11b5000060	3P CONTACTOR B500.00 60V
51adx0365	

Pmv80n A600	
Pmv10a440	
8lm2tb104 Taste Rote 8lm2tb104	
P/N: 000436 Type: Lvm25240	
11b4004sI00220	4P CONTACTOR220/240V W/O LATCH
Bgf09	
8lm2til104	
7gn2037u51	
Kltx8302v	
8lm2tc01 Nc	
Bg12	
11b63040095	4P CONTACTOR B630.4.00 95/125
Pmv20 A575	
008907 7gn328366u28nockenschalter 3 Pos. Fronteinbau	
Bf18	
Pmv70a575	
11b40000440	
8 Lp2t IIm5p Signal Lampe 8 Lp2t IIm5p Lovato	
Lovpmv70a575	
Bf16.04/220v-230v50-60hz	
000771	
Bf115 00a	
11b5004I00220220	4P CONTACTOR220/240V C/W LATCH 220VAC
Pma50 A480	
11b630I00220220	3P CONTACTOR 220/240V C/W LATCH 220VAC
11b125024110	3P CONTACTOR 1250A AC1 110V AC COIL
008071	
51adx0085b	
Pmv70 A575	

Pmvf 30	
8lm2tau120	
005789	
Bg0031a380-400v	
3sb52856hc03 (Yellow)	
11b63010000048	3P CONTACTOR B630/1000.00 48V IN AC1
B310	
8lm2til105	
Pmv20 A600	
11b250I00220c220	3P CONTACTOR220/240V C/W LATCH 220VDC
000941 / Tmm1	
Bg0031a220	
11 Bg06 01 A	
006066	
11g280	
11b3100060	3P CONTACTOR B310.00 60V
Pma30 240	
Vfs11-4022pl-Wp	DRIVE 2.2KW 4.2KVA 3HP 380/500VAC 50/60HZ
B145	
Pmv50 A575	
2153a95	
11b40040060	4P CONTACTOR B400.4.00 60V
Pmv50n A440	
31-Dcra7	CONTROL UNIT FOR GENERATING SETS DCRA SERIES 50HZ
11b40040095	4P CONTACTOR B400.4.00 95/125V
11b5000048	3P CONTACTOR B500.00 48VAC/DC
11sm1b16 / Sm1r0100	
Multimeter Dmk 32251 Dimensionport - Rs485	
P2I101312	
Bf150	

8lm2tc10 Kontaktelement	
51adx0470	
11b160024110	3P CONTACTOR 1600A AC1 110V AC COIL
Gx20-7900-U06	
Bgp09	
11b4000048	3P CONTACTOR B400.00 48V
Bf25.04/380-400v50-60hz	
B400	
11b31000500	3P CONTACTOR B310.00 500/550V
Pmvf 20 D048	
Dla1 10 24 (Ex La3c 25 24)	
11b630l00220c220	3P CONTACTOR 220/240V C/W LATCH 220VDC
8 Lm2t C01 (1 H3)	
Bf18 01 A	
Gx16h07u Nockenschalter	
11b31040060	4P CONTACTOR B310. 4 00 60V
51adx0060b	
009078 Gn258828unockenschalter	
Pmf20 A240	
Bf25	
51adx0820	
Pmv50a240 005216	
8 Lm2t B104	
11 Bg12 01 A	
11b63000110	
11b310400440	4P CONTACTOR B310.4 00 440-480
11b630l00110110	3P CONTACTOR 110/125V C/W LATCH 110VAC
51adx0075b	
51adx1200	
11sn1	

Exp10_12	
11b310400110	4P CONTACTOR 320A 110V AC/DC COIL
8lm2ts230 Schalter 8lm2ts230 Lovato	
8 Lm2t Au120	
51adx0125b	
Nfin. Mot. Sm1p 1,6-2,5 A (Sm1p0250)	
8 Lp2t Ilm4p Signal Lampe 8 Lp2t Ilm4p Lovato	
11 Bg12 10 A	
8lm2tlb8 Led-Lampe Mit Patrone 24 V Ac/Dc	
Kbf3s11 /001700	
Pmv55 A440	
Bf26	
Exp1015	
8lm2tel400	
Bf18 01 D	
11b50000110	
11b2504l00110c110	4P CONTACTOR110/125V C/W LATCH 110VDC
11b63010000060	3P CONTACTOR B630/1000.00 60V IN AC1
Exp10_10	
8lm2tb102	
P/N: 000249 Type: 11b40000220	
Exm10_01	
11 B1250 24	
Pmv70n A440	
7gn12 69u Schalter	
11b1600424110	4P CONTACTOR 1600A AC1 110V AC COIL
11g526	MAIN CONTACTS 3 POLE SET W ALLEN SCREWS KEY FOR CONTACT REPLACEMENT B630
006007 Exp1030.	
51adx0190b	

11 B250 00	
Pmv80n A240	
51adx0310	
001456 Cn2020024	
Bfk3200a110	
31bce1024	
51adx0142b	
Km B2 S02	
11b2504sI00220	4P CONTACTOR220/240V W/O LATCH
11b4004I00380c24	4P CONTACTOR380/415V C/W LATCH 24VDC
11b6304sI00220	4P CONTACTOR 220/240V W/O LATCH
11g272c220	
8lm2tc10 Block Mit Kontakt No	
Pmv70na600	
Bf16.04/380-400v50-60hz	
11b6300048	3P CONTACTOR B630.00 48V
8 Lm2t C10 (1 Ho)	
024874	
51adx0640	
DcrI5	
8lm2tau120 Montage-Adapter	
Exm10 11	
Pmvf 30 D048	
51adx0030b	
Adx0110b	
8lm2ts220 Schalter 8lm2ts220	
11b1250424220	4P CONTACTOR 1250A AC1 220V AC COIL
11b250I00110c110	3P CONTACTOR110/125V C/W LATCH 110VDC
11b40000110	
Exp10 03	
11b500I00110110	3P CONTACTOR110/125V C/W LATCH 110VAC

005707 / Pmv40a240	
000841	
Lov11b63000110	
Exm10_13	
11b500400220	4P CONTACTOR 520A 220V AC/DC COIL
11b2504I00220c220	4P CONTACTOR220/240V C/W LATCH 220VDC
005771	
Gx16h11u	
8lm2tsI1205 (Pack 1x10)	
11b2504I00220220	4P CONTACTOR220/240V C/W LATCH 220VAC
11 Bg09 10 A	
11b4004I00220220	4P CONTACTOR220/240V C/W LATCH 220VAC
Bf38t2d220	
11b400I00220c220	
5ladxm45bpa220	SOFT STARTER 45A 220V + BY-PASS
Kpb6s11 Endschalter	
Pma60 A480	
Pma20 240	
11b400400380	4P CONTACTOR B400.4.00 380/415
11 Bf ? 26 00 A230	
11b6301000400380	4P CONTACTOR B630/1000.4.00 380/415V
Lov-Vfs114007plw	
Pmvf 20	
Lodcrk12 Lovato Dcrg12	
11b4004I00220c220	4P CONTACTOR220/240V C/W LATCH 220VDC
11 Bg12 10 D	
8 Lm2t S130	
11b40040024	4P CONTACTOR B400.4.00 24V
Bf16	
Pmv20 A240	

Bf9.10/220v-230v50-60hz	
Sm1r0100	
8lm2tp100	
11bg1210a230	
001457 Cn2501024	
11b6301000400110	4P CONTACTOR 1000A AC1 110V AC/DC COIL
11b500I00380380	3P CONTACTOR380/415V C/W LATCH 380VAC
Pma60 A240	
Bf63000110	
Rgk800	
Exm10 10	
11b250I00110110	3P CONTACTOR110/125V C/W LATCH 110VAC
Der Regler Des Leistungsfaktors Lovdcrj12	
11b2504sl00110	4P CONTACTOR110/125V W/O LATCH
8lm2tb102 Schwarze Taste	
8lm2til104 Runder Kappe, Rot	
001341	
8lm2til103	
Bg0040a380	
11b400sl00220	3P CONTACTOR220/240V W/O LATCH
Lov11b50000110	
Pmv50 A240	
Pma50 A415	
8lm2ts133 Schalter	
11b3100024	3P CONTACTOR B310.00 24VAC
Pmvf 51	
11b5004I00220c220	4P CONTACTOR220/240V C/W LATCH 220VDC
11b400sl00110	3P CONTACTOR110/125V W/O LATCH
Bf38	
11b630100040048	4P CONTACTOR B630/1000.4.00 48V

11b4004sI00110	4P CONTACTOR110/125V W/O LATCH
11b500sI00110	3P CONTACTOR110/125V W/O LATCH
11b250I0060c48	3P CONTACTOR60V C/W LATCH 48VDC
11b500sI00380	3P CONTACTOR380/415V W/O LATCH
11 Bgp09 01 D	
Pmv30 A575	
005537	
Bf09	
Pmv70n A240	
11b125024220	3P CONTACTOR 1250A AC1 220V AC COIL
11b6304I00220220	4P CONTACTOR 220/240V C/W LATCH 220VAC
11b630sI00220	3P CONTACTOR 220/240V W/O LATCH
Bf50 00 E	
51adx0045b	
11b400I00110c110	3P CONTACTOR110/125V C/W LATCH 125VDC
Bf18t4d024 Nummer 004431	
Pmv70n A600	
11b630400380	4P CONTACTOR B630.4.00 380/415
Art. Nr. 000541 , 11bgp0910a048	
Bf50000110	
Lov51adx0110b	
Bf32	
11b160024220	3P CONTACTOR 1600A AC1 220V AC COIL
11b630sI00110	3P CONTACTOR 630A AC3 110VAC MECH.LATCH
Nfin. Mot. Sm1p 6,3-10a (Sm1p1000)	
8 Lt7 All M8 Led Bulb, White	
11b310400380	4P CONTACTOR B310.4.00 380/415
Pmv50n A600	
1no Lpx C10 Kontaktelement	
11g370 (Pack 1x10)	
8 Lp2 Tilm 3p Signal Lampe Lp2 8 Tilm	

3p Lovato	
11b31040024	4P CONTACTOR B310.4.00 24VAC
Pmv50 A600	
11 B630 1000 00	
11b4000060	3P CONTACTOR B400.00 60V
Exp1013	
11bg1210a012 3p Minicontactor Bg12.10a 12v 50-60hz	
Bf0901a024	
11b500sI00220	3P CONTACTOR220/240V W/O LATCH
Pmv30 A600	
3590a99	
11g270 Adaptor Fuer Relais Rf82 - Rf95	
Exp10 18	
B250	
11 Bf ? 26 00 A230 With Ciol 110v	
51adx0017b	
7qn258756u18	
Lov11b40000110	
003859	
51adxm45bpa480	SOFT STARTER 45A 480V C/W BYPASS
Pmv10 A440	
11b500I00220c220	3P CONTACTOR220/240V C/W LATCH 220VDC
11bg1210d024	
Nfin. Mot. Sm1p 4-6,5 A (Sm1p0650)	
Pmv80n A440	
Pmv55 A240	
11b25040048	4P CONTACTOR B250.4.00 48V
Dla110	
002461 Cn2020220	
Bf40	

[Bf12 10 A](#)

[005537 - Gn1210u2551](#)

[8lm2ts231 Schalter Mit Langem Griff3
Positionen \(Ohne Befestigungselement
Basis\)](#)

[Exp10 13](#)

[547020](#)