



## Terasaki

Garanti: 12 ay

Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.

**Terasaki** Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

*Firmamız Terasaki Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.*

rn	Aıklama
<a href="#">Breakers Model S225-Gf 150 A / 225 Ampere Frame -</a>	- WITH BACK PLATE
<a href="#">Breakers Model S400-Gf 250 A / 400 Ampere Frame -</a>	- WITH BACK PLATE
<a href="#">3p Pmc S630-Ne 600 Amper</a>	
<a href="#">3p Pmc S400-Ne 400 Amper</a>	
<a href="#">3p Pmc S225-Gf 225 Ampe</a>	
<a href="#">3p Pmc S100-Gf 75 Ampe</a>	
<a href="#">3p Pmc Hibe-103 50 Ampe</a>	
<a href="#">Acb08rc</a>	Configured 800A ACB MK2 Body Replacement to replace AR208S s/n: 06107-818 8536209090 JPN Containing 106208992 208S 3P Drawout ACB Body 116101200 Protection Relay AGR-21BS-PS AC110/240V 116152025 -B Backlit LCD Display 08-63 116102007 Sensor Kit 3 X 800A 208-220 116103306 AC110V Charging Motor for LCD OCR 08-20S 116104106 AC110V Continuously Rated Closing Coil 114105100 MK2 UVT Coil Only Type AUR-1B-AC 116109001 Position Switch Body 08-40 DO 116112001 Close-Open Cycle Counter 116425002 IP31 Door Flange 116118200 Main Shutter Action Plate 08-32 DO 116122101 Control Safety Shutter Body 08-63 DO 116128001 Auto-Discharge Device 08-20S DO 116423002 Storage Draw-Out Handle
<a href="#">S125-GJ for PLUG-IN BASE (Spare Parts)</a>	

<a href="#">TKC125</a>	TERASAKI CONTACTOR TKC 125 (Code: N/A) AC1=160A AC3=1120A AC 100-240V 50/60 HZ DC 100-240V PLEASE SEE ATTACHED PHOTOS FOR MORE DETAILS
<a href="#">S225-GE 200A</a>	16 Molded Case Circuit breaker With base
<a href="#">S100-NM 60A</a>	17 Molded Case Circuit breaker
<a href="#">E-50CM 8A</a>	18 Molded Case Circuit breaker
<a href="#">XS50CB 3P 20A PLUG IN MCCB</a>	
<a href="#">MODEL: H250-NJ</a>	TRIPLE POLE MOLDED CASE CIRCUIT BREAKER (PLUG-IN TYPE ) WITH OVERLOAD & SHORT CIRCUIT RELEASE MAKE: TERASAKI MODEL: H250-NJ AMPERE FRAME:250AF AMPERE TRIP:250AT ULTIMATE BREAKING CURRENT / SERVICE BREAKING CURRENT (Icu/Ics)= 125/85kA @ 415V,50Hz
<a href="#">Our Part No.: 871.001.00.041</a>	CIRCUIT BREAKER TYPE:TL-100F, DC3P; I - 125A, AC 690V, 50-60 Hz
<a href="#">Our Part No.: 871.001.00.0288</a>	Maker's No: 11 Drawing No.: M03469-PLB3 Our Part No.: 871.001.00.0288 Component: 871.001 - MAIN SWITCHBOARD
<a href="#">381430</a>	
<a href="#">12563</a>	
<a href="#">800047</a>	
<a href="#">596612</a>	
<a href="#">255045</a>	
<a href="#">60267</a>	
<a href="#">800160</a>	
<a href="#">110248</a>	
<a href="#">110250</a>	
<a href="#">110251</a>	
<a href="#">112101</a>	
<a href="#">110451</a>	
<a href="#">EARTH LEAKEGE RELAY TZS-AD AC 120/240V</a>	
<a href="#">EARTH E-LEAKEGE TORROID TERESAKI- TZS-24</a>	
<a href="#">XS400N5</a>	
<a href="#">T25AD24-240</a>	
<a href="#">250a-1600a</a>	

<a href="#">282020350</a>	
<a href="#">Xs125nj 3p 50a Fc Mccb</a>	
<a href="#">Nke-4295</a>	
<a href="#">Xs1250ne ( Is The Exact Breaker As The Xs1250se)</a>	
<a href="#">T2mc80 1000a</a>	
<a href="#">Xs125nj 63a 3p Fc Mccb</a>	
<a href="#">Ar216s, 3p</a>	
<a href="#">Esm-105e2</a>	
<a href="#">98.6.049.706</a>	
<a href="#">Aur-1cd/Ac200*Ass</a>	
<a href="#">Xs1250/1600 (Aux)</a>	
<a href="#">As9883 Tzs-40</a>	
<a href="#">Din-T10h380c</a>	
<a href="#">Erc233</a>	
<a href="#">S50-Nf 3p 30a Fc Mccb</a>	
<a href="#">Aor-1cl-Al Ct Ratio: 600/3a</a>	
<a href="#">Xv125nj</a>	Moulded Case Circuit Breakers Air Circuit Breakers Kompaktleistungsschalter Luft-Leistungsschalter
<a href="#">Din-T Auxiliary</a>	
<a href="#">S160-Sj 4p 160a Fw</a>	
<a href="#">Xs1250/1600se (Hend)</a>	
<a href="#">Tzs - Ad / Ac 120/240 V</a>	
<a href="#">S400-Nj 3p</a>	
<a href="#">Dtcb6316c</a>	
<a href="#">Anu-2</a>	
<a href="#">Tzs-Ad Ac 120 / 240 V</a>	
<a href="#">400 A</a>	
<a href="#">Dtcb6320c</a>	
<a href="#">Aop 1la</a>	
<a href="#">Gj 100</a>	
<a href="#">Aop-1la-A (3200/5a)</a>	

<a href="#">Dtcb6332c</a>	
<a href="#">Mk3 Ac200-240</a>	
<a href="#">125af</a>	
<a href="#">Xs50nb 20a 3p Fc Mccb</a>	
<a href="#">1250af</a>	
<a href="#">S125-Nj 3p 50a Fc Mccb Std Type</a>	
<a href="#">Ar440s, 3p</a>	
<a href="#">Dtcb6350c</a>	
<a href="#">Aru-3d</a>	
<a href="#">3200a 4p - -Obsolete, Replaced By Acb32rc</a>	
<a href="#">Aop-1la-G+ (630/5a) V</a>	
<a href="#">291240000</a>	
<a href="#">Tkk85 Thermal Overload Relay</a>	
<a href="#">Dh06d20002</a>	
<a href="#">T2mc40 630a</a>	
<a href="#">Coil For At12</a>	
<a href="#">Tns2</a>	TESTER
<a href="#">812095, S800-Cj 3p 800a Fc Mccb</a>	
<a href="#">At25</a>	
<a href="#">S250-Nj 3p 160a Fc Mccb Std Type</a>	
<a href="#">Esm-103l</a>	
<a href="#">3*400a</a>	
<a href="#">206520580 Xs800nj 800a 3p Fc Mccb</a>	
<a href="#">Dtcb6310c</a>	
<a href="#">Aop-1la-A (2000/5a)</a>	
<a href="#">Acb16, At16 1600a</a>	
<a href="#">1h0828dbb</a>	
<a href="#">Aop-1la-G+ Aop-1u (320/5a)</a>	
<a href="#">Dtcb6310d</a>	
<a href="#">At20 2000a (Addacb)</a>	

<a href="#">Ern-312</a>	
<a href="#">S160-Sj 4p 160a Fc</a>	
<a href="#">Xh250nj</a>	
<a href="#">Dint10h-Hs</a>	
<a href="#">Gdt720</a>	
<a href="#">291240000 Tzs-Ad E/L Relay</a>	
<a href="#">Atb-4037y Auto Transformer</a>	
<a href="#">250af Xh250nj..3p.160a</a>	
<a href="#">98.6.030.702</a>	
<a href="#">378577</a>	
<a href="#">Tkc9 85</a>	
<a href="#">Gj250</a>	
<a href="#">Xc125nj Not Exists</a>	
<a href="#">Anu-1 Ocr Obsolete! By Anu-1b-Ac200</a>	
<a href="#">Ar212s</a>	
<a href="#">S125-Nj 3p 63a Fc Mccb Std Type</a>	
<a href="#">S160-Gj</a>	
<a href="#">Dtcb6363c Mcb Din-T6 6ka 3p</a>	
<a href="#">Xs400nj</a>	CIRCUIT BREAKER 400AMP 3POLE
<a href="#">Ar212h</a>	
<a href="#">At25 2500a</a>	
<a href="#">Xh225ns 125 Amp</a>	
<a href="#">300 A</a>	
<a href="#">Aor-1cl-AI Ct Ratio: 300/3a</a>	
<a href="#">Acb12, Configured 1250a Acb</a>	
<a href="#">Esm-103 M Obsolete/Replaced With Esm-103I</a>	
<a href="#">630a5</a>	
<a href="#">Xs125nj 63a 4p Fc Mcc</a>	
<a href="#">Tzs 40</a>	

<a href="#">As9884 Tzs-24</a>
<a href="#">Tzs-Ad E/L Relay</a>
<a href="#">250 A</a>
<a href="#">Xs800-Se</a> CIRCUIT BREAKER 800AMP 4POLE 8KV 690VAC
<a href="#">3*250a</a>
<a href="#">Erc-297</a>
<a href="#">98.6.034.704</a>
<a href="#">14144-607</a>
<a href="#">As8279</a>
<a href="#">K / 87z / 6-001b, Esm-105 - By Esm-105e2</a>
<a href="#">Tzs-Ad / Earth Leakege Relay (Tzs-Ad)ac 120/240 V / Erdungsleckrelais</a>
<a href="#">Tzs Hc</a>
<a href="#">800-1600a</a>
<a href="#">1h3619cag</a>
<a href="#">Erc-411</a>
<a href="#">S125</a>
<a href="#">Aur-1cd</a>
<a href="#">Aop-1la-G +aop-1u (630/5a)</a>
<a href="#">Dtcb6204c Mcb Din-T6 6ka 2p</a>
<a href="#">Tkc-65 , Tc-65a</a>
<a href="#">000348</a>
<a href="#">Agr-21s-Pru/Ac*Un</a>
<a href="#">3ab Auxiliary Switch</a>
<a href="#">At32 3200a</a>
<a href="#">2h1192cac</a>
<a href="#">Erc-232</a>
<a href="#">S 125</a>
<a href="#">S50-Sf 30a European Code, Asian Code S50-Nf 3p 30a Fc Mccb</a>
<a href="#">414730660</a>

<a href="#">S125-Nj 3p 125a Fc Mccb Std Type</a>
<a href="#">Dtcb6325c</a>
<a href="#">Aor-1bs-As (Btob0024a)</a>
<a href="#">Aop-1la-A (1600/5a)</a>
<a href="#">710t2nl</a>
<a href="#">Auxiliary Contact For Xs1250nd</a>
<a href="#">Dtcb6363c</a>
<a href="#">Gm2h63</a>
<a href="#">Dh06d20004</a>
<a href="#">Ar220s, 3p</a>
<a href="#">Xs1250se, Art N: 206670512</a>
<a href="#">Xs800nn</a>
<a href="#">Aop-Iu (630/5a)</a>
<a href="#">S250</a>
<a href="#">Acb25 Configured 2500a Acb</a>
<a href="#">Xh125n</a>
<a href="#">Xs30nb - Not Available, Alternative - Xs50nb 20a 3p Fc Mccb</a>
<a href="#">Xh250pe 250a 4p Fc Mccb (204280725)</a>
<a href="#">Alarm Sswitch For Xs1250nd</a>
<a href="#">Add2500af</a>
<a href="#">Acb32rc</a>
<a href="#">Din-T10h3100c</a>
<a href="#">Aor-1bl-Gs</a>
<a href="#">Tc-65a</a>
<a href="#">3*315-320a</a>
<a href="#">Xh125nj 50a 3p Fc Mccb (204124550)</a>
<a href="#">Aux Sw Micro 1c</a>
<a href="#">Ds06</a>
<a href="#">S250-Nj 3p 250a Fc Mccb Std Type</a>
<a href="#">Aop-Iu (320/5a)</a>

<a href="#">Tn-S2</a>
<a href="#">Agr-21s-Pru/Ac*Un 1h1754caa</a>
<a href="#">800a2</a>
<a href="#">4p160a+sd Qd+sd</a>
<a href="#">Ac380-440v Uvt 0.5sec Td</a>
<a href="#">1h1752caa</a>
<a href="#">Tzs-24</a>
<a href="#">Tkk85 , By Range Of Temcontact2 (Need Also New Connector)</a>
<a href="#">Erc-311</a>
<a href="#">3*200a</a>
<a href="#">212 S</a>
<a href="#">Btvb0010a</a>
<a href="#">Ar332s-R 3200a 3p D/O Acb</a>
<a href="#">Ar332s, 3p</a>
<a href="#">Mac-2s Egs-112c</a>
<a href="#">Xs1250se-G (01.02.0036), Xs1250/1600 Aux (01.02.0037)</a>
<a href="#">Zctzs-40 - Tzs-40</a>
<a href="#">At40fd</a>
<a href="#">Sht Ac 200-240v 125af-1000af</a>
<a href="#">Dtcb6340c</a>
<a href="#">Mpr-6-Dgf</a>
<a href="#">Dtcb6102c Mcb Din-T6 6ka 1p</a>
<a href="#">215002014</a>
<a href="#">Aop-1la-A (1250/5a)</a>
<a href="#">Tem Power At32 , Ar332s-R 3200a 3p D/O Acb And At32 3200a</a>
<a href="#">Alarm Sw Micro 1c</a>
<a href="#">Tzs Ad Relay</a>
<a href="#">At 12 Sn:5116-29</a>

<a href="#">S125-Ne</a>
<a href="#">Xs1250se-G</a>
<a href="#">Ltf/Lts</a>
<a href="#">Ah-6b</a>
<a href="#">E50-Sf 3p Pmc</a>
<a href="#">(01.02.0038), Ltf/Lts (01.02.0055)</a>
<a href="#">Erb-111 Pcb</a>
<a href="#">Acb16 Configured 1600a Acb</a>
<a href="#">S400</a>
<a href="#">At16</a>